

Desk Tool Caddy

Materials:

- 1 5 x 7 plastic desk top frame
- 2 6 x 16 rectangles (front and back background)
- 1 7-1/2 x 9 rectangle (front pocket 1)
- 1 7 x 11 rectangle (front pocket 2)
- 1 6-1/2 x 12 rectangle (back pocket)

Front assembly

1. Fold 7-1/2 x 9 fabric (pocket 1) in half, wrong sides together so unit measures 7-1/2 x 4-1/2.
2. Top stitch along fold.
3. Baste 1/4" from bottom edge of fabric.
4. Mark the middle of the fabric from top to bottom and 1-3/4" from middle line.
5. Fold the 7 x 11 inch fabric (Pocket 2) in half wrong sides together. Unit will measure 7 x 5-1/2. Top stitch along folded edge. Draw a line down the center.
6. Place pocket 1 on top of pocket 2 matching center lines and stitch down this line. Back stitch to reinforce the stitching at the top.
7. Evenly gather the fabric at the bottom and stitch down the other two marked lines. This will make 4 pockets.
8. Fold 6 x 16 fabric (front background) in half lengthwise. Unit will measure 6 x 8.
9. Place pocket 1 and 2 on background. (Pockets will be facing background) Sew 1/4 inch on the bottom easing in extra fabric.
10. Turn pockets to the back side and iron so seam is on the bottom.
11. Match sides and baste or pin.
12. Sew pocket 1 and 2 to background at center line.

Back assembly

1. Fold 6-1/2 x 12 fabric (back pocket) in half wrong sides together. Unit will measure 6-1/2 x 6. You can adjust this pocket depending on what you want to put in it.
2. Top stitch along fold.
3. Fold 6 x 16 fabric (back background) wrong sides together. Unit will measure 6 x 8.
4. Sew bottom of back pocket to background fabric easing in extra fabric.
5. Turn pocket to back side and iron so seam is on the bottom.
6. Pin or baste sides.
7. Place front and back pockets facing together matching all seams. Folds will be on top.
8. Sew 1/4" along sides and top.
9. Turn inside out and place on picture frame and fill with your favorite tools.